


Quick Start Guide

A) Unpacking instructions:


1. The display must be installed or carried by two or more people
2. It is recommended that you retain your packaging and foam in case the display is transported

①



Remove outer sleeve.

②



Take off top protective packing.

③




Remove the display.


B) Operating instructions: To connect the OSTENDO CDM43 display to your computer, follow these instructions:

Note: Make sure to read the user's manual before installation. In order to display the maximum resolution, a video card that supports output resolution of 2880 x 900 is needed.

1. Power off your computer.
2. Determine whether your computer supports DVI-D and/or HDMI output.
 - a. Use supplied data cable between computer and CDM43 as shown below



3. Connect the other end of the cable to the corresponding port on the CDM43 back panel.
4. Connect the power cable to the power port on the CDM43 back panel.



5. After all connections have been made, press the CDM43 power button (right most button) on the front panel control buttons to power on the display.
6. Power on your computer.
7. Depending on your computer graphics card, the low resolution start up screens may not appear on the CDM43. Once the computer is past its boot-up phase, content should appear normally.
8. The CDM43 will automatically detect the input type and switch to the appropriate mode. If you are using both cable types, the "Select" button on the display's front panel will toggle between them.
9. Using the display settings of the computer, set the display resolution to be 2880 x 900.
10. Once the CDM43 is displaying an image, consult your user manual for vertical, horizontal alignment, blend region and sharpness tuning if needed. Validate your calibration settings with your commonly used applications.